

STEPPING STONES



YOU WILL NEED

- A bag of pre mixed cement.
- Large plant leaves
- Gloves
- Mixing container
- Cardboard

1. Mix up the concrete in a plastic container., making sure to wear gloves
2. On a piece of cardboard lay a large leaf and cover with at least 2cm thick of concrete.
3. Leave to dry a few days and peel off leaf revealing your concrete leaf.
4. Paint with premium paint from Mirror Paints



SIGN UP TO OUR NEWSLETTER AT
www.mirrorpaints.com.au